
Pottery Barn – Pottery Barn Teen – Pottery Barn Kids – Williams Sonoma Home – West Elm – Rejuvenation – Mark and Graham-GreenRow

10-September-2024 1/8



# **WARREN**

Pottery Barn - Pottery Barn Teen - Pottery Barn Kids - Williams Sonoma Home - West Elm - Rejuvenation - Mark and Graham-GreenRow

10-September-2024 2/8

### <u> AENGLISH</u>

#### **CAUTION:**

 Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.

### **Important Safety Instructions:**

- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture
- We strongly recommend that a professional electrician install all direct wire fixtures.
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A
  PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS
  INVOLVED.
- The lighting fixture is meant for indoor use. It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
- For your safety, it is strongly recommended that two people install the lighting fixture.
- This fixture has been rated for up to one (1) 60-watt maximum E27 TYPE A standard light bulb (not included) or one (1) 4-watt maximum E27 TYPE A LED light bulb (not included) To avoid the risk of fire, do not exceed the recommended lamp wattage.
- The lighting fixture is meant for indoor use. SUITABLE FOR DRY LOCATIONS ONLY.
- Save these instructions.

#### **WARNING:**

- To reduce the risk of fire, electrical shock or personal injury, always turn off the light fixture and allow it to cool prior to replacing the light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- · Keep flammable materials away from lit bulb.

#### PRE-ASSEMBLY:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.


### **Care instructions:**


- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

 $Pottery\ Barn\ Teen-Pottery\ Barn\ Kids-Williams\ Sonoma\ Home-West\ Elm-Rejuvenation-Mark\ and\ Graham-GreenRown and Graham-GreenRow$ 

10-September-2024 3/8

If ceiling are concrete, brick or plaster, please consult your local hardware store for assistance. For safety and ease of mounting, installation is recommended using two people. For stud mounting the anchors are not required, use only the Wall Screws.







Pottery Barn – Pottery Barn Teen – Pottery Barn Kids – Williams Sonoma Home – West Elm – Rejuvenation – Mark and Graham-GreenRow

10-September-2024 4/8

#### **Parts Included**




#### **Hardware Enclosed**



Pottery Barn – Pottery Barn Teen – Pottery Barn Kids – Williams Sonoma Home – West Elm – Rejuvenation – Mark and Graham-GreenRow

10-September-2024 5/8




### **Assembly & Installation Instructions:**


- SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
- Carefully unpack all fixture parts and hardware and lay them on a clear workspace.


Pottery Barn - Pottery Barn Teen - Pottery Barn Kids - Williams Sonoma Home - West Elm - Rejuvenation - Mark and Graham-GreenRow


10-September-2024 6/8



Find the Terminal Brown(B) by opening the cover of plastic Junction Box in the Canopy. Carefully inspect the Terminal Brown (B), the terminal marked "L" is to connect to Live/Hot Wire of power supply cable and the terminal marked "N" is to connect to Neutral wire of power supply cable, Insert the electrical wire of power supply cord through the rubber tubing of Plastic Junction Box and correctly connect the wires of power supply cable to the Terminal Brown (B). Seal the Plastic Junction Box by putting its cover back after completing electrical wire connections.








Pottery Barn – Pottery Barn Teen – Pottery Barn Kids – Williams Sonoma Home – West Elm – Rejuvenation – Mark and Graham-GreenRow

10-September-2024 7/8



Pottery Barn – Pottery Barn Teen – Pottery Barn Kids – Williams Sonoma Home – West Elm – Rejuvenation – Mark and Graham-GreenRow

10-September-2024 8/8

#### To Make the Wire Connections:

- Gently pull existing wire down from the ceiling junction box and allow wires to hang. The HOT or LIVE wire is usually Brown.
   The NEUTRAL wire is usually Blue. Check to see if there is a ground wire that is usually green with a yellow stripe or exposed copper metal wire. If need, use a pair of wire strippers to remove about 1/2 inch of insulation from each wire.
- 2. Carefully inspect the fixture wires. The NEUTRAL FIXTURE WIRE is Blue. The HOT FIXTURE WIRE is Brown, and the GROUND WIRE is Yellow/Green WIRE. If you have any doubt and cannot identify the power-supply wires with confidence, then we recommend that you ask an electrician and that you not continue with the installation.

NOTE: IT IS IMPERATIVE THAT THE JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED! DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

3. Check the wiring connections and if all looks good, gently tuck the wire connections neatly into the ceiling junction box.